

# IQeye501 パスワード設定

security画面で設定します。

IQeye501 IQEYE012D98

live playback image window network **security** trigger IQrecorder multiview

**Passwords** ?

general protection enabled  
authentication mode basic  
change general password \*\*\*\*\*  
change management password  
retype management password

**Access Hours** ?

weekdays on  
weekends on  
camera is on (24 hour HH:MM) 00:00  
camera is off 00:00

**Camera License** ?

License File  参照...  
upload

**On-Camera Intelligent Software**

IQauthenticate: Not Installed  
IQrecorder: Installed

general protection をenabledにしますとパスワード認証画面が直接出ます。

同じパスワードを入力します。

**passwords** ?

general protection disabled  
authentication mode basic  
change general password basic  
change management password secure  
retype management password

basic 一般的なパスワード認証

secure 暗号化したより安全なパスワード認証

アドレス http://192.168.0.60/

general protection をenabled にしますとこの画面からパスワードを入力します。

ネットワーク パスワードの入力

ユーザー名とパスワードを入力してください。

サイト: 192.168.0.60  
領域: IQEYE012D98

ユーザー名(U)   
パスワード(P)

このパスワードを保存する(S)

OK キャンセル