IQeye501 ソフトウエアのバージョンUP(1)

IQEYE Reference Manual 166~170ページ参照(DOS コマンドプロンプトを使用して FTP転送します。)



IQeye501 ソフトウエアのバージョンUP(2)

IQEYE Reference Manual 166~170ページ参照(DOS コマンドプロンプトを使用して FTP転送します。)



IQeye501 ソフトウエアのバージョンUP(3)

IQEYE Reference Manual 166~170ページ参照(DOS コマンドプロンプトを使用して FTP転送します。)

画 コマンド プロンプト - ftp 192.168.0.65	
Microsoft Windows XP [Version 5.1.2600] (C) Copyright 1985-2001 Microsoft Corp.	ftp>の終了コマンド quitを入力し enterを押します。
C:¥Documents and Settings¥tsutomu>ftp 192.168.0.65 Connected to 192.168.0.65. 220 FTP Version 1.1 on IQeye501 User (192.168.0.65:(none)): root 331 Password required. Password: 230 logged in with privs, proceed. ftp> bin 200 type set to I ftp> put iqeye5.svs 200 PORT set to 192.168.0.5,(20,1700) 150 Opened port 1700. 226 Successfully programmed flash. Rebooting. Connection closed by remote host. ftp> quit	
ត コマンド オレンナト 	
Microsoft Windows XP [Version 5.1.2600] (C) Copyright 1985-2001 Microsoft Corp.	▲ コマンドプロンプト初期画面が出ましたらDOS の終了コ マンドの exitを入力して画面を閉じます。
C:¥Documents and Settings¥tsutomu>ftp 192.168.0.65 Connected to 192.168.0.65. 220 FTP Version 1.1 on IQeye501 User (192.168.0.65:(none)): root 331 Password required. Password: 230 logged in with privs, proceed. ftp> bin 200 type set to I ftp> put igeye5.sys 200 PORT set to 192.168.0.5,(20,1700) 150 Opened port 1700. 226 Successfully programmed flash. Rebooting. Connection closed by remote host. ftp> quit	
C:¥Documents and Settings¥tsutomu>exit	
IQeye501 Route_246	IQinvision @
Image: Strapshot Image: Strapshot Imag	security の画面からcamera licenseをアップロードします。 IQeye501 の画面にvideo clipの表示が追加されます。
Preside the resolution is the	is Web ページ ダ ▼ 280x720 ? per sec): > Cancel